


## Installation Guide For 2 Core and 4 Core FTTH Drop Cable



### 2 CORE/4 CORE FTTH CABLE USED IN FLOOR


Installation Guide For 4 Core Type:

1. 4 Core FTTH Drop Cable go through Vertical Pipeline to every Floor.

2. Using 4 Way Tap to export 4pcs individual Fibers, make 4 Fibers as "Reserved Fiber")

3. When user asking for FTTH service, operator Join the "Reserved Fiber" to another 1 Core FTTH Drop Cable By Mechanical Splicer (another FTTH Drop Cable To the home)

4. Another 1 Core Home Cable connected with Mechanical splicer to the ONU.



## Installation Guide For Mechanical Splicer

